



1996-2000 Honda Civic Coolant Flush

A video tutorial on how to change and do a coolant flush on the cooling system of a 1996-2000 Honda Civic.

Written By: eCuration



INTRODUCTION

The coolant system should be flushed once every two years.

Follow this video guide by YouTuber [NutzAboutBolts](#) to do the change yourself.



TOOLS:

- [Hydraulic Floor Jack](#) (1)
- [Jack Stand](#) (1)
- [Wheel Chocks](#) (1)
- [Oil Drain Pan](#) (1)
- [Long Neck Funnel](#) (1)
- [3/8" Drive Ratchet](#) (1)
- [10" Ratchet Extension](#) (1)
- [10mm Socket](#) (1)
- [Flathead Screwdriver](#) (1)
- [Phillips #2 Screwdriver](#) (1)
- [Large Needle Nose Pliers](#) (1)
- [Hose Pliers](#) (1)



PARTS:

- [Engine Coolant](#) (1)

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-10-08 12:31:48 AM.